## Principle of operation



## Principle of operation

**Refrigerant vapour (1)** circulates through an **evaporative condensing coil (2)**, which is continuously wetted by the **spray system (3)** installed at the top of the condenser. At the same time the **direct driven radial fans (4)**, located at the bottom of the unit, blow ambient **air (5)** upwards through the condenser.

During operation, heat is transferred from the refrigerant to the water, and then to the atmosphere as a portion of the water that evaporates. The condensed vapour then **exits the unit (6)**. The remaining spray water that falls on the **sloping channels (7)** continuously flows into the **sloping sump (8)**, where the water is collected. **Access louvers (9)** prevent water splash-out to the dry section. The spray water **pump** (10) recirculates the water up to the water spray system. The warm saturated **air (11)** leaves the condenser through the drift **eliminators (12)**, which remove water droplets from the air.

**Interested in the Polairis condenser?** Contact your local <u>BAC</u> <u>representative</u> for more information.

